Nepton 280

A
x4
B
x8
C
x4
D
x1
E
x8
F
x8
G
x4
H
x4
I
x2
J
x2
K
x1
L
x4
M
x1
N
x4
O
x2


1
INTEL
AMD
I
F


2
INTEL
AMD
B
E
Or


3
INTEL
AMD
D


4
AMD
H
O


5
AMD
N
C
K
AMD


6
AMD
AMD
K


7
AMD
G


8
AMD
A

Asia Pacific - Cooler Master Technology Inc.
8F, No. 786-1, Zhongzheng Rd., Zhonghe Dist., New Taipei City 23586, Taiwan (R.O.C.)
Tel : +886-2-2225-2627
Service: service@coolermaster.com.tw

CHINA - Cooler Master China
5F., Building B, No. 18, HeChong E. 4th Rd., Zhongkai, Hui Zhou City, Guong Dong Province, China
Tel : +86-752-260-8898
Service: web@coolermaster.com.cn

EUROPE - Cooler Master Europe B.V.
Hustonweg 3 Trade Port West 9272, 5928 LW Venlo, The Netherlands
Service: support@coolermaster.nl

USA - Cooler Master USA
4620 Schaefer Ave. Chino CA 91710, USA
Service: support@coolermaster.com

Global Live Help
http://www.coolermaster.com/livehelp

©2013 Cooler Master Technology Inc. All Rights Reserved. All trademarks are registered to their respective owners.
For more information, please visit our official website: http://www.coolermaster.com

1 INTEL



2 INTEL



3 INTEL LGA1366/1156/1155/1150/775



4 INTEL LGA1366/1156/1155/1150/775



5 INTEL LGA1366/1156/1155/1150/775



6 INTEL LGA2011



7 INTEL LGA2011



8 INTEL AMD